## Operator Tips Operator Tips

## **Data to Record**

The following data should be recorded on the glassine filter envelope during filter changes. Also record the monitor's 3-digit ID-number. Please do not staple or tape the glassine envelopes – our sample prep lab folks will thank you!

STP TOTAL SAMPLING VOLUME [m3] typically between 3,000 and 10,000

UTC SAMPLING START date & time time is in 24-hour format, and UTC (not local time)

UTC MEASUREMENT STOP date & time is in 24-hour format, and UTC (not local time)

